

DESCRIPTION

The 3MTS is an easy-to-use handheld Teslameter/Gaussmeter to measure all 3 magnetic field components simultaneously within a very small a volume. It comes in two different versions.

In the 3MTS-1 the 3-axis Hall probe is mounted in a thin but robust carbon-fiber holder attached to the electronic control module.

In the 3MTS-2 the small 3-axis hall probe is connected with a flexible cable to the electronic control module. This is ideal for measuring fields in difficult to access places.

The integrated on-chip temperature sensor allows to generate a temperature compensated measurement output.

The 3MTS is connected with an USB cable to a PC or tablet for control, data acquisition and data visualization. All three components and the total value of the magnetic field as well as the probe temperature are displayed by the 3MTS software graphically. The easy to use software supports export of the measured data and includes alarm triggers and min/max hold functions.

The 3MTS has been developed by Senis in cooperation with its partner company Matesy.

KEY FEATURES

- Handheld Teslameter/Gaussmeter with 3axis Hall probe
- Compact, light and robust packaging
- 3MTS-1: Carbon-fiber probe holder for high robustness and flexibility
- 3MTS-2-Xm: Ceramic probe connected by a thin cable
- Hall probe thickness, including holder: 1 mm
- Measurement ranges: 100 mT, 500 mT, 3 T and 20 T
- Calibration certificate for 100 mT and 500 mT included
- Accuracy: better than ±1.0 % of full range
- Frequency bandwidth: DC to 0.5 Hz
- AD Conversion: 12 bit
- Computer Interface: USB2, USB3
- User-friendly software for Windows
- Numerical and graphical visualization of all three components of the magnetic field, B_X, B_Y and B_z as well as B_{TOTAL}, B_{MAX}, B_{MIN} and probe temperature
- Alarm, MIN/MAX Hold and Zeroing functionality
- Data export to CSV / Excel
- Application programming interface (API) for integration in 3rd party software



Figure 1: 3MTS-1 (left) and 3MTS-2-2m (right) USB Handheld Teslameters

Ref.No.: DS.200.3MTS.18 Rev. 2.2 / 20.08.2018

PHONE +41 44 508 70 29
FAX +41 43 205 26 38
E-MAIL info@senis.ch

Neuhofstrasse 5a 6340 Baar, Switzerland

SENIS AG





Magnetic measuring properties	Value				
Measurement ranges: Brange	±100 mT	±500 mT	±3 T	±20 T	
Noise level (peak to peak, 6σ)	400 μΤ	1.4 mT	8.0 mT	-	
Noise level (1s averaging time, peak to peak, 6σ)	50 μT	100 μΤ	400 μT	-	
Accuracy (% of B _{RANGE})	1 %	1 %	2 % (±2 T) 3 % (±3 T)	5 % (estimated	
Calibration at reference magnetic field	±50 mT	±100 mT	-	-	
Field Sensitive Volume (FSV) XxYxZ	(150x10x150) μm				
Angular accuracy	<±2° with respect to the reference surface				
Long term stability	<1 % over 10 years				
Electrical properties					
AD Conversion	12 bit				
Sampling frequency	1 kHz				
Frequency bandwidth	DC to 0.5 kHz				
Operation temperature	(-20 to +85) °C				
Operation temperature ceramic probe and cable (3MTS-2)	(-20 to +160) °C				
General properties					
Product Versions	3MTS-1: Probe integrated in carbon probe holder 3MTS-2-X: Ceramic probe connected with cable (X: length of cable in m)				
Weight	20 g (3MTS-1)				
Dimensions (LxWxH)	3MTS-1: (162 x 22.5 x 10.5) mm Electronic box: (62 x 22.5 x 10.5) mm				
Scope of delivery	3MTS USB-Cable Memory stick with software, API, manuals Plastic carrying case				
Computer requirements	Microsoft Windows 7, 10 Compatible with USB 2.0 or 3.0				




Figure 2: Dimensions of the field-sensitive volume of the fully integrated 3-axis Hall sensor chip.



Figure 3: Plastic carrying case

Ref.No.: DS.200.3MTS.18 Rev. 2.2 / 20.08.2018

PHONE +41 44 508 70 29 FAX +41 43 205 26 38 E-MAIL info@senis.ch





3MTS-1 SPECIFICATIONS




Figure 4: Standard dimensions of 3MTS Handheld Teslameter, the carbon-fiber probe holder and position of the field sensitive volume (FSV). All measures are given in millimeters.

Dimensions	X [mm]	Y [mm]	Z [mm]
Center of the field sensitive volume (FSV)	2.5 ± 0.1	-0.65 ± 0.05	-1 ± 0.1
Dimensions of carbon probe holder dimensions	5.0	100	1.0

Ref.No.: DS.200.3MTS.18 Rev. 2.2 / 20.08.2018

PHONE +41 44 508 70 29 FAX +41 43 205 26 38 E-MAIL info@senis.ch





3MTS-2 SPECIFICATIONS




Figure 5: Dimensions of the Hall probe and position of the Field Sensitive Volume (FSV)




Figure 6: Coordinate system




Figure 7: Conceptual design of electronic box and cabling of Hall probe

Cable specification	Description		
Copper braided flexible cable	Ø 0.7mm x 50 mm		
	\varnothing 1.7 mm ± 0.1 mm x 1 m (optional 2 m and 5 m)		
CaH cable	Twisting: 15 x Diameter		
	Shield: Silver plated soft copper braid		
	Jacket: PFA		

Ref.No.: DS.200.3MTS.18 Rev. 2.2 / 20.08.2018

PHONE +41 44 508 70 29 FAX +41 43 205 26 38 E-MAIL info@senis.ch







Figure 8: a) Graphical visualization of the measured data (Bx, By, Bz, Btotal, T); b) Numerical presentation of the measured data (Bx, By, Bz, Btotal, T), Hold MAX/MIN and alarm function; c) Setup tab and data output

Typical Applications



- Quality control and monitoring of permanent magnets & magnet systems
- Measurement of the environmental magnetic field
- Development of magnet systems & process control
- Magnetic field mapping
- Applications in production lines and laboratories

Ref.No.: DS.200.3MTS.18 Rev. 2.2 / 20.08.2018

PHONE +41 44 508 70 29 FAX +41 43 205 26 38 E-MAIL info@senis.ch

